

2002

# Sprinklers, Crop Water Use, and Irrigation Time: Sanpete County

Robert W. Hill

Craig Poulson

Follow this and additional works at: [http://digitalcommons.usu.edu/extension\\_histall](http://digitalcommons.usu.edu/extension_histall)

 Part of the [Agriculture Commons](#)

**Warning:** The information in this series may be obsolete. It is presented here for historical purposes only. For the most up to date information please visit [The Utah State University Cooperative Extension Office](#)

---

## Recommended Citation

Hill, Robert W. and Poulson, Craig, "Sprinklers, Crop Water Use, and Irrigation Time: Sanpete County" (2002). *All Archived Publications*. Paper 174.

[http://digitalcommons.usu.edu/extension\\_histall/174](http://digitalcommons.usu.edu/extension_histall/174)

This Article is brought to you for free and open access by the Archived USU Extension Publications at DigitalCommons@USU. It has been accepted for inclusion in All Archived Publications by an authorized administrator of DigitalCommons@USU. For more information, please contact [dylan.burns@usu.edu](mailto:dylan.burns@usu.edu).





## **SPRINKLERS, CROP WATER USE, AND IRRIGATION TIME SANPETE COUNTY**

*Robert W. Hill*, Extension Specialist - Irrigation  
*Craig Poulson*, County Agent - Sanpete County

March 2002

ENGR/BIE/WM/29

Sprinkler irrigation has been an important part of Utah's agricultural production since the early 1950s. About 40% of Utah's 1.3 million irrigated acres are watered with sprinklers, including hand move, wheel move, center pivot and other types. In Sanpete County, the percent of sprinkler irrigated cropland is higher than the state average at about 45%. Of the 94,000 acres of irrigated cropland in the county, approximately 42,000 acres are irrigated by sprinklers. Sprinklers can be a good investment when properly designed, installed, maintained and managed. For every acre-foot of water supplied to an efficient sprinkler system a farmer can expect to harvest about 1 3/4 tons of alfalfa and 46 bushels of wheat. In contrast, the expected harvest with a typical surface irrigation system (flood or furrow) is less than 1 1/4 tons of alfalfa or about 30 bushels of wheat for each acre-foot of water applied. Sprinklers apply water more efficiently and uniformly than typical surface irrigation systems, thus they produce more yield for each acre-foot of water.

Not all water applied by an irrigation system is used by the crop. Some water is lost to deep percolation, evaporation, or runoff. Application efficiency (Ea) is a term that tells how much of the water applied by the system is actually stored in the root zone for crop use. In Utah a typical sprinkler system has an Ea of 70% which means that 70% of the water applied by the sprinkler heads is actually stored in the soil for crop use. The actual Ea depends upon how evenly the sprinklers distribute water as well as other factors such as operating pressure, nozzle size and spacing, sprinkler maintenance condition, wind, air temperature and humidity (day versus night), and irrigation scheduling. In Utah, the average efficiency of surface irrigation is less than 50% as compared to the higher sprinkler efficiency values of more than 65% for well managed systems.

### **SPRINKLER IRRIGATION MANAGEMENT**

An efficient sprinkler system is the result of good system design, proper irrigation scheduling and careful operation and timely maintenance.

## DESIGN

A well designed sprinkler system applies water uniformly to the soil surface, and is capable of applying enough water to meet the peak demands of the crop without producing excess runoff. Good design considers such factors as pressure, nozzle size and spacing; wind, air temperature and humidity (day versus night); soil intake rate; crop rooting depth and water use rates.

The flow rate from a sprinkler nozzle depends upon nozzle size and water pressure. Flow rates for selected nozzle sizes and pressures are given in Table 1. Typical sprinkler flow rates may vary from 4 gallons per minute (gpm) from a 5/32-inch nozzle at 30 pounds pressure to over 11 gpm from a 7/32-inch nozzle at 70 pounds pressure. The nozzle size is usually stamped on the side of the nozzle. Wheelmove systems typically have 3/16-inch nozzles.

On sloping fields there may be considerable pressure differences between sprinkler heads on high and low ends of the line. In this situation, flow control nozzles may be used to improve the uniformity of water application. Flow control nozzles apply water at nearly the same rate when operated within the rated pressure range of the nozzle.

### Precipitation Rate (How hard is it raining?):

The Precipitation Rate (Pr) is the rate at which water is delivered from the nozzle, averaged as inches per hour, over the area covered by one nozzle. It is important to consider the Pr when designing a sprinkler system, since water will run off if applied faster than the soil can absorb it. Precipitation rate can be calculated using the following formula:

$$Pr \text{ (inches/hr)} = 96.3 \times \text{nozzle flow rate (gpm)/area covered (ft}^2\text{)} \quad (1)$$

**Table 1. Sprinkler Pressure and Flow Rate.**

Nozzle size	Nozzle Pressure, psi				
	30	40	50	60	70
Inch	Nozzle flow rate, gallons per minute (gpm)				
5/32	3.9	4.5	5.0	5.4	5.8
11/64	4.7	5.4	6.0	6.6	7.1
3/16	5.5	6.3	7.0	7.7	8.3
13/64	6.4	7.4	8.2	9.0	9.7
7/32	7.4	8.6	9.6	10.5	11.3

Note: Flow rates are for agricultural sprinkler heads with brass nozzles. Sprinkler nozzle flow rate is proportional to the square root of the water pressure at the base of the nozzle, thus doubling the pressure does not double the flow rate.

Precipitation rate can be calculated as follows: In a typical wheelmove system, each sprinkler covers 2400 square feet. This is based on a spacing of 40 feet between sprinklers on the line, and a 60 foot move ( $40' \times 60' = 2400$  square feet). With 3/16 inch nozzles that are operating at 50 pounds pressure, the nozzle flow rate is 7.0 gpm (from Table 1). The precipitation rate would be:

$$Pr = 96.3 (7.0 \text{ gpm})/2400 \text{ ft}^2 = 0.28 \text{ inches per hour}$$

**Application Rate (How much of the rain stays in the soil?):**

The Application Rate (Ar) is the average rate at which water is stored in the soil, in inches per hour.

$$Ar = \text{Application Efficiency (Ea)} \times \text{Precipitation rate (Pr)} \quad (2)$$

Typical sprinkler application efficiency values vary from 60% to 80%, with 70% a reasonable average.

**Example:**

$$Ar = (70/100) \times 0.28 \cong 0.20 \text{ inches per hour}$$

**How Long to Irrigate (Duration):**

The duration of irrigation needed to store the crop irrigation requirement (evapotranspiration, Et) in the root zone is:

$$\text{Irrigation Duration (hours)} = \text{Crop Irrigation requirement (inches)}/Ar \quad (3)$$

**Example:** Determine how many hours to irrigate in July. Assume a crop irrigation requirement (Et) of 8.5 inches, 3/16 inch diameter nozzles operated at 50 psi and 40' x 60' spacing (use results of previous examples).

$$\text{Hours to irrigate in July} = 8.5 \text{ inches}/0.20 \text{ inches/hour} \cong 43 \text{ hours}$$

Assuming that the sprinklers were moved twice per day (11 1/2 hour sets) then about four irrigations ( $4 \cong 43/11.5$ ) are needed in July. This is equivalent to one 11 1/2 hour irrigation about every 8 days [ $8 \cong 31/(43/11.5)$ ].

Calculated irrigation duration for nozzle sizes of 5/32 to 7/32 and pressures of 50 and 60 psi are given in Table 2. The durations shown in Table 2 were obtained from the use of Table 1 and Equations 1, 2, and 3, assuming sprinkler spacing of 40' by 60' and 70% application efficiency. The Table 2 duration value corresponding to the above example is 43.2 hours, which is found at the intersection under the 3/16 nozzle, 50 psi column and the 8.5 inches of water required row. Crop water use estimates for Utah are given in Hill (1994).

## IRRIGATION SCHEDULING

Irrigation scheduling is the process of determining when to irrigate and how much water to apply. It depends upon design, maintenance, and operation of the irrigation system and the availability of water. The objective of irrigation scheduling is to apply only the water that the crop needs, taking into account evaporation, seepage, runoff losses, and leaching requirements.

Scheduling is especially important to pump irrigators if power costs are high. Common irrigation scheduling approaches include the following:

1. Irrigation on fixed intervals or following a simple calendar, i.e., when a water turn occurs or according to a predetermined schedule.
2. Irrigating when the neighbor irrigates.
3. Observation of visual plant stress indicators.
4. Measuring (or estimating) soil water by use of instruments or sampling techniques such as probes.
5. Following a soil-water budget based on weather data and/or pan evaporation.
6. Some combination of the above.

**Table 2. Required Irrigation Duration for Selected Irrigation Water Requirement Values.**

Irrigation Water Req'd, inches	Nozzle size, inches									
	5/32		11/64		3/16		13/64		7/32	
	Pressure psi									
	50	60	50	60	50	60	50	60	50	60
	Irrigation Duration, Hours									
0.5	3.6	3.3	3.0	2.7	2.5	2.3	2.2	2.0	1.9	1.7
1.0	7.1	6.6	5.9	5.4	5.1	4.6	4.3	4.0	3.7	3.4
1.5	10.7	9.9	8.9	8.1	7.6	6.9	6.5	5.9	5.6	5.1
2.0	14.2	13.2	11.9	10.8	10.2	9.2	8.7	7.9	7.4	6.8
2.5	17.8	16.5	14.8	13.5	12.7	11.6	10.9	9.9	9.3	8.5
3.0	21.4	19.8	17.8	16.2	15.3	13.9	13.0	11.9	11.1	10.2
3.5	24.9	23.1	20.8	18.9	17.8	16.2	15.2	13.8	13.0	11.9
4.0	28.5	26.4	23.7	21.6	20.3	18.5	17.4	15.8	14.8	13.6
4.5	32.0	29.7	26.7	24.3	22.9	20.8	19.5	17.8	16.7	15.3
5.0	35.6	33.0	29.7	27.0	25.4	23.1	21.7	19.8	18.5	17.0
5.5	39.2	36.3	32.6	29.7	28.0	25.4	23.9	21.8	20.4	18.6
6.0	42.7	39.6	35.6	32.4	30.5	27.7	26.1	23.7	22.3	20.3
6.5	46.3	42.9	38.6	35.1	33.1	30.1	28.2	25.7	24.1	22.0
7.0	49.8	46.2	41.5	37.8	35.6	32.4	30.4	27.7	26.0	23.7
7.5	53.4	49.4	44.5	40.5	38.1	34.7	32.6	29.7	27.8	25.4
8.0	57.0	52.7	47.5	43.2	40.7	37.0	34.7	31.6	29.7	27.1
8.5	60.5	56.0	50.4	45.9	43.2	39.3	36.9	33.6	31.5	28.8
9.0	64.1	59.3	53.4	48.5	45.8	41.6	39.1	35.6	33.4	30.5
9.5	67.6	62.6	56.4	51.2	48.3	43.9	41.2	37.6	35.2	32.2

Note: Irrigation duration, hours, calculated from flow rate in Table 1 and from Equations (1), (2), and (3) assuming sprinkler spacing of 40' by 60' and 70% application efficiency. Irrigation water required is equivalent to crop evapotranspiration, if rainfall is ignored (see Table 3).

For irrigation scheduling to be most useful at a specific location, the following should be done:

1. Evaluate the irrigation system. Determine application depth, efficiency, and operating capabilities and constraints.
2. Select an appropriate irrigation scheduling method.
3. Monitor performance at intervals during the growing season.
4. Perform a post-season evaluation and determine changes for next year.

## **OPERATION AND MAINTENANCE**

To realize the full benefit of the sprinkler system, it must be operated according to design and properly maintained throughout the irrigation season. This may involve special operating techniques such as using an offset hose or alternating between day and night on successive irrigation cycles to improve distribution uniformity. Where pressure differences within a sprinkler system result in low uniformity of water application, special hardware such as flow control nozzles or pressure regulators may be required.

An audit or evaluation of the irrigation system is recommended if you suspect that the system is not as efficient as it should be. An audit determines application depth, distribution uniformity, and hydraulic performance of the supply system. If a pump is used, it is tested to determine fuel or energy use efficiency. An audit may also identify steps to improve system operation and maintenance.

Good operation also includes matching the set time (or rotation time with a center pivot) with the applied irrigation water depth and application rate to maximize the fraction of water stored in the root zone. Field irrigation (application) efficiency is the ratio of water stored in the root zone divided by the water delivered to the field. For example, if 50 acre inches of water are delivered to a 10 acre field during an irrigation and 30 acre inches are stored in the root zone then the application efficiency ( $E_a$ ) is 60% ( $60 = 100 \times 30/50$ ). If a field is under-irrigated, a high irrigation efficiency could result with a low uniformity. Conversely, an over-irrigated field will have a low irrigation efficiency, regardless of the high uniformity, because of the deep percolation. Thus, a knowledge of the soil moisture content prior to irrigation is essential to maintaining a high application efficiency while providing for optimum crop water use and growth.

## **CROP WATER USE**

The single most important factor influencing plant growth and crop yields is soil water availability. A good understanding of how water influences crop growth is essential for good water management. Water is the most massive of the inputs to crop yield. It takes 120 pounds of water (evapotranspiration only) to produce 1 pound of potatoes, 560 pounds of water for 1 pound of alfalfa hay and 790 pounds of water for 1 pound of wheat.

Soil water availability is affected by infiltrated irrigation water and rainfall, drainage and evapotranspiration. The crop irrigation requirement, or evapotranspiration ( $E_t$ ), is the combination of transpiration from plant leaves plus evaporation from adjacent soil surfaces. While crop  $E_t$  can be measured, it is most often estimated with equations from weather data collected locally. Estimated average monthly crop water use ( $E_t$ ) for alfalfa, corn, garden, pasture, spring grain, and turf in Ephraim, Gunnison, and Moroni are given in Table 3. Seasonal  $E_t$  for all crops in Gunnison is lower than in the north end of the county. However,  $E_t$  is similar between Ephraim and Moroni for all crops.

Assuming that the soil water depletion is completely replenished with each irrigation, the irrigation requirement is equal to  $E_t$  minus effective rainfall. As a general rule, field crops should

be irrigated whenever the soil water depletion approaches 50% of the available water in the root zone (see Appendix). This minimizes crop stress and keeps yields high. In the peak crop water use period in an arid area, the occurrence of rain is often neglected in determining an irrigation schedule.

**Table 3. Monthly Crop Evapotranspiration for Ephraim, Gunnison, and Moroni. Thirty year average for period 1961 - 1990.**

Site	Mar	Apr	May	Jun	Jul	Aug	Sep	Oct	Season Total
<b>Alfalfa Water Use, Inches</b>									
Ephraim		1.17	6.77	6.44	7.82	7.80	4.39	1.26	35.64
Gunnison		0.44	5.81	5.92	7.14	6.59	4.30	0.33	30.54
Moroni		1.15	6.65	6.08	7.81	7.83	4.53	1.30	35.35
<b>Corn Water Use, Inches</b>									
Ephraim			0.77	2.40	6.73	7.86	3.86		21.62
Gunnison			0.55	2.01	6.23	7.32	4.64		20.75
Moroni			0.76	2.27	6.72	7.89	3.99		21.63
<b>Garden Water Use, Inches</b>									
Ephraim			1.28	3.16	6.20	6.12	1.37		18.14
Gunnison			0.91	2.91	6.51	5.22	1.11		16.66
Moroni			1.25	2.99	6.20	6.15	1.42		18.00
<b>Pasture Water Use, Inches</b>									
Ephraim		1.26	4.47	5.66	6.22	5.39	3.73	0.82	27.55
Gunnison		0.63	4.15	5.24	6.16	5.01	3.75	0.83	25.77
Moroni		1.25	4.39	5.35	6.21	5.41	3.85	0.84	27.32
<b>Sp Grain Water Use, Inches</b>									
Ephraim		0.95	5.89	8.71	6.05				21.59
Gunnison		0.69	4.99	8.06	7.23				20.97
Moroni		0.94	5.79	8.23	6.04				20.99
<b>Turf Water Use, Inches</b>									
Ephraim		1.39	3.92	4.88	5.36	4.65	3.21	1.33	24.73
Gunnison		1.01	3.73	4.51	5.30	4.32	3.24	0.71	22.82
Moroni		1.31	3.85	4.61	5.35	4.66	3.32	1.04	24.14

Adapted from: Consumptive Use of Irrigated Crops in Utah, Utah Agricultural Experiment Station Research Report No. 145. Oct. 1994.

## CALCULATING AN IRRIGATION INTERVAL

The information needed to determine the interval between irrigations is available soil water in the root zone, crop water use (Et) rate (inches per day), and allowable soil water depletion at irrigation. Conversely, the irrigation system applied water depth (if fixed for all irrigations) could be used in place of the allowable depletion.

**Example A:** Simple Irrigation Calendar. Determine the irrigation interval and application depth for alfalfa on sandy loam soil at Ephraim. Use July Et and a root depth of 5 ft. Irrigate when one half of the available soil water has been depleted, i.e., when the management allowed depletion (MAD) is 50%.

From Table 3, June Alfalfa Et at Ephraim is 7.82 inches  
Average daily Et rate = 7.82 inches/31 days = 0.25 inches/day.

Soil water holding capacity (silty clay loam) is 2.0 inches/ft (from Appendix).  
Root zone available water = 5 ft  $\times$  12.0 inches of water/ft = 10.0 inches of water.

At a MAD of 50% depletion between irrigations, the irrigation amount is  $10.0 \times .5 = 5.0$  inches for each irrigation.

Irrigation interval = Irrigation amount/daily Et rate = 3.8 inches/0.25 inches per day  $\approx$  20 days.

**Summary:** Irrigate every 20 days, storing 5.0 inches of irrigation water in the root zone.

**Example B:** Alternate irrigation interval if wheel move sprinklers are moved twice per day. Assume 3/16 inch nozzles at 50 psi and 40 ft by 60 ft spacing (see examples with equations 1, 2, and 3 previously), and the same situation as in Example A above.

The net irrigation is 2.3 inches stored in the soil (2.3 inches = an application rate of 0.20 inches per hour  $\times$  11.5 hours per set).

The irrigation interval = 2.3 inches/0.25 inches per day = about 9 days.

**Summary:** Irrigate every 9 days, storing 2.3 inches of irrigation water in the root zone.

Both of these examples use the average daily Et rate for the month to illustrate the calculations. If a real time soil water budget method of irrigation scheduling were used, it would account for the day to day variations in Et and rain. This would result in a varying the irrigation interval as needed.

## SUMMARY

Good sprinkle irrigation requires:

- Understanding of Soil-Water-Plant Relationships
- Proper irrigation timing and amount depends on soil water holding capacity, weather, and crop growth progress
- Adequate Design and Installation
- Proper Operation and Maintenance
- Dedication and Commitment of Resources to Manage (i.e., the ***WILL*** to manage)



## ACKNOWLEDGMENTS

This fact sheet originated with a request from Marlon Winger (Carbon County) and Dennis Worwood (Emery County). Their contribution to the first of these county specific fact sheets is appreciated. This fact sheet was peer reviewed by Howard Neibling, University of Idaho Irrigation Specialist; Rich Koenig, Utah State University Soil Fertility Specialist; Steve Rogers, USDA - NRCS Area Engineer; and Utah Extension Agents: James Barnhill, Dean Miner, and Shawn Olsen. Their time and valuable suggestions are greatly appreciated. The word processing and electronic publication skills of Melanie Christoffersen and Donna Falkenborg are also gratefully acknowledged.

## APPENDIX

Soil Texture	<u>Available Water-holding Capacity of Soils</u>		<u>Typical Crop Rooting Depths</u>	
	Inches of available water per foot of moist soil	Permeability rate <sup>1</sup> Inches/Hour	Crop	Typical active root Zone depth, feet
Sands and fine sands	0.5 - 0.75	1.0 - 10	Alfalfa	5
Very fine sands, loamy sand	.8 - 1.0	1.0 - 3	Corn	4 - 5
Sandy Loam	1.2 - 1.5	0.5 - 3	Small Grains	3 - 4
Loam	1.9 - 2.0	0.3 - 0.8	Dry Beans	3
Silt loam, silt	2.0	0.2 - 0.4	Pasture	1 ½ - 2 ½
Silty clay loam	1.9 - 2.0	0.01 - 0.2	Potatoes	1 ½ - 2 ½
Sandy clay loam, Clay loam	1.7 - 2.0	0.1 - 0.6	Turf	1 - 2
			Vegetables	1 ½ - 3

Note: Allowable depletion to avoid crop water stress is usually about 50% of available water holding capacity for most field crops.

<sup>1</sup>Normal ranges. Intake rates vary greatly with soil structure and structural stability.

The web site address for “Consumptive Use of Irrigated Crops in Utah,” UAES Research Report #145, and the data tables used in Table 3 herein is found by going to the Utah Division of Water Rights home page at: <http://nrwrtl.nr.state.ut.us/>

Then select “Publications” and then select “Consumptive Use Tables.”

## BIBLIOGRAPHY

Hill, R.W. 1991. Irrigation Scheduling. Chapter 12 in Modeling Plant and Soil Systems, John Hanks and J.T. Ritchie (eds.), American Society of Agronomy, Inc., Crop Science Society of America, Inc., Soil Science Society of America, Inc., Madison, WI. 491-509.

Hill, R.W. 1994. Consumptive Use of Irrigated Crops in Utah. Utah Agr. Exp. Stn. Res. Report No. 145, Utah State University, Logan, UT. Oct. 370 pp. Revised and reprinted Feb. 1998.

Hill, R.W., and R.G. Allen. 1996. Simple Irrigation Scheduling Calendars. Journal Irrigation and Drainage Division. ASCE. 122:2, March/April.

Hill, R.W. , R.J. Hanks, and J.L. Wright. 1984. Crop Yield Models Adapted to Irrigation Scheduling Programs. Utah Agr. Exp. Stn. Res. Report 99.

For additional reading/resource material see:

Larsen, D.C. and T.S. Longley. "Nozzle Management and Leak Prevention for Sprinkler Irrigation." Current Info. Series No. 569. University of Idaho Coop. Extension Service, Moscow, ID 83843. MSU Agronomy Notes Series numbers 44, 47, 49, 53, 102, and 122. J.W. Bauder. Soil and Water Specialist; Plant, Soils and Environmental Science Department, Montana State University, Bozeman, MT 59717. Telephone (406) 944-5685; email: [jbauder@montana.edu](mailto:jbauder@montana.edu).

Pacific Northwest Extension Publication, PNW Series numbers 286-292. Jan. 1986. Available from University of Idaho Cooperative Extension Service, Moscow, ID 83843. Titles in this series include: *Pumping Plant Efficiencies, Offsets for Stationary Sprinkler Systems, Irrigation Runoff Control Strategies, Irrigation Scheduling, Converting Sprinkler Systems to Lower Pressure, Sizing Irrigation Mainlines and Fittings, Electrical Demand Charges-How to Keep them Low, Extending Electric Motor Life.*

Additional information on wheel move sprinkler management is available on the Utah State University web site at:

<http://extension.usu.edu>

Select "Publications" and then select "Irrigation Engineering"

BIE/WM-05 "Maintenance of Wheelmove Irrigation Systems"

BIE/WM-08 "Wheelmove Sprinkler Irrigation Operation and Management"

## WHERE CAN YOU GET HELP?

### Utah State University - Extension Service

USU Extension, Biological  
and Irrigation Engineering  
4105 Old Main Hill  
Logan, UT 84322-4105  
[bobh@ext.usu.edu](mailto:bobh@ext.usu.edu)  
(435) 797-2791

USU Extension Office  
Sanpete County Extension  
325 West 100 North  
Ephraim, UT 84627  
[craigp@ext.usu.edu](mailto:craigp@ext.usu.edu)  
435-283-7582

---

Robert W. Hill, Extension Irrigation Specialist,  
Biological and Irrigation Engineering Department,  
Utah State University, Logan, UT 84322-4105

Craig Poulson, County Agent - Sanpete County  
Utah State University, Logan, UT 84322

---

Utah State University is committed to providing an environment free from harassment and other forms of illegal discrimination based on race, color, religion, sex, national origin, age (40 and older), disability, and veteran's status. USU's policy also prohibits discrimination on the basis of sexual orientation in employment and academic related practices and decisions.

Utah State University employees and students cannot, because of race, color, religion, sex, national origin, age, disability, or veteran's status, refuse to hire; discharge; promote; demote; terminate; discriminate in compensation; or discriminate regarding terms, privileges, or conditions of employment, against any person other wise qualified. Employees and students also cannot discriminate in the classroom, residence halls, or in on/off campus, USU-sponsored events and activities.

This publication is issued in furtherance of Cooperative Extension work. Acts of May 8 and June 30, 1914, in cooperation with the U.S. Department of Agriculture, Jack M. Payne, Vice President and Director, Cooperative Extension Service, Utah State University. (EP/DF/03)